

## **Guidelines for 6” SEWER TAP INSPECTION**

The following guidelines and procedures have been developed to assure proper inspection of sewer taps.

Boot over main must be secured and tight.

6” line used for property clean out must come off boot and have a cap on it.

All 6” taps are made on a 45° degree angle.

Metro Codes inspects from property clean out to structure.